



CLIPS AND ATTACHMENTS

Various accessories to fasten nets to wires/cables:

1. **Plastic Clip** - locking the net, after creating a hem. Between the two clip parts by the brackets, 50 cm between clips.
2. **Plastic Clip with a bridge** - as above, when the net house cord is inserted in the bridge.
3. **Pin** - a smooth plastic needle, with a handle and a push button for convenient insertion and to prevent releasing of the pin. 40 cm between pins.
4. **Metal clip** - 20 cm wide, especially suitable for 30% black shading net. 50 cm between clips.
5. **Stork clip** - to be used only in nets with strengthening strings at the edges. 40 cm between the clips.
6. **Fast connection clasp** - fastens to the bridge clip (only), and enables fastening and releasing of cables and wires.



CLIPS AND ATTACHMENTS




Fastening a net with a plastic clip



Fastening a net with a bridge clip



Fastening a net with a bridge clip and a fast connection clasp




Incorrect fastening:
The string is pulled out of the stitches


When the net is fastened, a stork clip section of the net should be included to prevent pulling the string out the stitches




Fastening a net with a pin clip to the wire



A net fastened to the wire with a pin clip



Two nets fastened to both sides of the same wire with pin clips



Two nets fastened to both sides of the same wire with stork clips